


CIRCUIT™ BENCH

SURFACE MOUNT INSTALLATION INSTRUCTIONS




FOR ALL SURFACE MOUNTED CIRCUIT BENCHES STEP BY STEP





Mark hole locations


• Place bench in desired location. Mark center of each hole location with a pencil.



Drill holes

• Use hammer drill to drill 2-1/4" deep x 5/8" diameter anchor hole at each marked location using a 5/8" drill bit suitable for concrete drilling.

NOTE: Forms+Surfaces recommends starting holes with 3/16" diameter drill bit followed by 3/8" and finally 5/8" for maximum accuracy.



Insert & set anchors


- Use compressed air and steel wire brush to clean each anchor hole.
- Insert 1/2"-13 x 2" anchor (a) into each anchor hole and use hammer to tap anchor tops flush with ground level.
- Use 1/4" punch and hammer to set anchors by driving down the center of each anchor until it stops.

FORMS+SURFACES®

CIRCUIT™ BENCH


SURFACE MOUNT INSTALLATION INSTRUCTIONS

STEP BY STEP FOR ALL SURFACE MOUNTED CIRCUIT BENCHES




Position bench

• Position bench so that mounting holes line up with anchors.



Attach bench

• Insert 1/2"-13 x 1-1/2" tamper-resistant flathead cap bolt (b) into each mounting hole in bench and thread into anchors using 5/16" hex bit for tamper-resistant bolts.



Tighten bolts

• Tighten bolts until snug.