



BIKE GARDEN™ BIKE RACK

CAST-IN-PLACE INSTALLATION INSTRUCTIONS

TOOLS NEEDED




STEP BY STEP FOR ALL CAST-IN-PLACE BIKE GARDEN BIKE RACKS




Create space for footer

- A sufficient footer size depends on frost and other conditions to be determined by the installer. A minimum of a 10" diameter x 18" deep footer *per bike rack stem* is recommended. Bike rack stems placed in close proximity to one another can share a common footer.



Position and support bike rack

- Position bike rack in desired final location and support so concrete can be poured in hole around bike rack stem.
- Bottom of bike rack stem should be embedded 10" into concrete.
- Use level to ensure bike rack is level.




Pour concrete footer

- Mix concrete and pour footer according to concrete manufacturer's instructions.
- As soon as footer is poured, check levelness and re-level if needed.
- Allow concrete to cure completely according to concrete manufacturer's instructions before removing any temporary supports.

BIKE GARDEN™ BIKE RACK

CAST-IN-PLACE INSTALLATION INSTRUCTIONS

RECOMMENDED BICYCLE RACK SPACING PER ASSOCIATION OF PEDESTRIAN AND BICYCLE PROFESSIONALS (APBP) GUIDELINES FOR ALL BIKE GARDEN BIKE RACKS



T 800.451.0410 | www.forms-surfaces.com

FORMS+SURFACES®

© 2015 Forms+Surfaces® | All dimensions are nominal. Specifications and pricing subject to change without notice. For the most current version of this document, please refer to our website at www.forms-surfaces.com.